

Mirror Tube Removal for either Transmitted path (TR) or Reflected Path (RP):

- 1) Loosen the 3 Knurled Ring Retainer Screws
- 2) Remove (unscrew) Knurled Ring with the attached lens tubes
- 3) Loosen the 6 Mirror Tube Screws
- 4) Remove 1 Mirror Rotation Screw
- 5) Remove Mirror Tube from Housing (slides out)









